

PERFORMANCE BENEFITS:

- A highly effective powdered cleaner for the removal of organic and colloidal foulants.
- Highly buffered to resist pH changes during the cleaning process.
- Designed specifically for both microfiltration (MF) and ultrafiltration (UF) membrane systems.
- Suitable for use with other AvistaClean MF formulations.

AvistaClean® MF 1000 powder is a proprietary, one-step cleaner used to remove foulants from microfiltration (MF) and ultrafiltration (UF) membrane surfaces and pores. This cleaner acts on organic and particulate foulants and is compatible with the MF/UF modules offered by major membrane manufacturers.

AvistaClean MF 1000 is NSF certified for off-line use in drinking water systems and can be used in conjunction with AvistaClean MF 3000 when membrane foulants contain calcium carbonate and/or metals.

INSTRUCTIONS FOR USE
Cleaning

Below are general guidelines for cleaning MF/UF systems. Please consult your system's manufacturer for more detailed instructions.

1. Fill the cleaning tank with reverse osmosis (RO) permeate or deionized water. If neither of these water sources is available, softened water may be used. Do not dissolve cleaners in hard water. The water volume required for cleaning is generally equal to the total volume of the system, hoses and cartridge filters.
2. Heat the water to the maximum temperature allowed by the MF/UF module manufacturer, usually 104°F (40°C).
3. When the water is hot, add the AvistaClean MF 1000 to the tank. Thoroughly dissolve the cleaner either by recirculating water through the tank or using a mechanical mixer. Add sufficient AvistaClean MF 1000 to create a 2% wt/wt solution if the fouling is moderate to severe or a 1% wt/wt solution if the fouling is mild.
4. With the filtrate valve shut, recirculate the cleaner through the modules in the feed direction for 30 minutes (for tubular designs only). After 30 minutes, reverse the flow direction, from the exit to the feed, for an additional 30 minutes.
5. Modules with a back flush design can be back flushed with cleaning solution in the filtrate-to-feed direction for 15 minutes, in addition to the recommended cleaning procedure.
6. Flush the system with soft water or MF/UF filtrate if suitable.

Please consult your sales representative for further technical or logistical details and always review the SDS before use to ensure suitable safety precautions are followed.

CORPORATE OFFICES

Avista Technologies, Inc.
Global Headquarters
 140 Bosstick Boulevard
 San Marcos, California 92069
 United States

Tel. | +1.760.744.0536



Avista Technologies (UK) Ltd
 13 Nasmyth Square, Houstoun Industrial Estate
 Livingston, EH54 5GG
 United Kingdom

Tel. | +44 (0) 131 449 6677

www.avistatech.com

PRODUCT INFORMATION
Packaging and Storage

Standard regional pack sizes are listed below. Information on drumless or bulk tanker delivery is available on request.

SPECIFICATIONS

Appearance: White powder

pH (2% solution): 10.9-12.4

| PACKAGING FORMAT | AMERICAS/ ASIA | EMEA |
|------------------|----------------|-------|
| Pail | 45 lb | 20 kg |
| Carboy | 90 lb | - |
| Drum | 350 lb | - |